

512K Cache SRAM

JS1
JS2

M5 32Kx8 (TA9)

M1 128Kx8

M2 128Kx8

M3 128Kx8

M4 128Kx8

Chapter 4

Award BIOS Setup

The 486-PIO-2 comes with the Award BIOS chip that contains the ROM Setup information of your system. This chip serves as an interface between the processor and the rest of the main-board's components. This chapter explains the information contained in the Setup program and tells you how to modify the settings according to your system configuration.

CMOS Setup Utility

Award BIOS Setup Utility AWARD SOFTWARE, INC.	
STANDARD CMOS SETUP	SUPERVISOR PASSWORD
BIOS FEATURES SETUP	USER PASSWORD
CHIPSET FEATURES SETUP	IDE AUTO DETECTION
POWER MANAGEMENT SETUP	SAVE & EXIT SETUP
PCI CONFIGURATION SETUP	EXIT WITHOUT SAVING
LOAD BIOS DEFAULTS	
LOAD SETUP DEFAULTS	
File: 001	1 -> Select Item
F10 : Save & Exit Setup	Esc/F2 : Change Color
Time, Date, Hard Disk Type.	

A Setup program, built into the system BIOS, is stored in the CMOS RAM. This Setup utility program allows changes to the motherboard configuration settings. It is executed when the user changes system configuration; user changes system backup battery; or the system detects a configuration error and asks the user to run the Setup program. After power-on RAM testing, the message "Press DEL to enter SETUP" appears. Use the arrow keys to select and press <Enter> to run the selected program.