

Table of Contents

Chapter 1 Overview

Package Checklist	1
The VA-503+ Motherboard	2
Main Features	3
Intelligent Properties	5

Chapter 2 Installation Procedures

1). Set System Jumpers	7
Jumpers	7
Motherboard Layout	8
Clear Password: CPW	10
Flash ROM Type Selection: EP1, EP2	10
Power Supply Type Selection: PWR	11
CPU to SRAM Data Transacting Mode Selection: SRAM	11
2). Install System RAM Modules	12
RAM Module Configuration	12
Install and Remove SIMMs	13
Install and Remove DIMMs	13
DIMM Frequency: CLK4 , SDRAM 1 & System Frequency: SDRAM2, SDRAM3	15
Cache Memory	16
3). Install the CPU	17
CPU External (BUS) Frequency: CLK1, CLK2, CLK3	18
CPU to Bus Frequency Ratio: FREQ1, FREQ2, FREQ3	18
Set CPU Frequency:	19
Set CPU Voltage	20
4). Install Expansion Cards	21
5). Connect Cables and Power Supply	22
Keyboard Connector: AT_KB	22
Serial Port Connectors: COM1, COM2	22
Universal Serial Bus Connectors: JUSB	22
CPU Fan Connector: CPU_FAN	23
EISCA CPU Fan Connector: EICA	23
Printer Connector: LPT	23

Table of Contents

Floppy Diskette Drive Connector: FDD	24
Remote Power Connector: CN5	24
IDE HDD Device Connectors: PRIMARY, SECONDARY.....	24
PS/2 Mouse Connector: MS_CON.....	25
System Case Fan Connector: CHAS_FAN	25
Infrared Connector: IR.....	25
Front Panel Block Connector: F_PNL.....	26
PS/2 Keyboard and Mouse Connector: KB, MS (<i>manufacturing option</i>)	27
AT Power Supply Connector: POWER	28
ATX Power Supply Connector: ATX_PWR (<i>manufacturing option</i>)...	28
Remote Wake-Up Connector: RWU.....	28
Chapter 3 BIOS Setup	
CMOS Setup Utility.....	29
Standard CMOS Setup	30
Hard Disk Configurations.....	30
Software Turbo Speed.....	31
BIOS Features Setup.....	32
Chipset Features Setup.....	35
Power Management Setup.....	38
PNP/PCI Configuration	42
Load BIOS Defaults	44
Load Setup Defaults.....	44
Integrated Peripherals	44
Supervisor/User Password.....	48
IDE HDD Auto Detection.....	49
Save and Exit Setup	50
Exit without Saving.....	50
Appendix Software Utilities	
Starting Installation.....	51
Desktop Management Interface (DMI).....	51
Starting DMI.....	51
Editing DMI.....	52
Adding DMI.....	52
Loading DMI	53
Saving DMI	53
Bus Master IDE Driver	54

Table of Contents

Installation	54
Patch for Chipset.....	55
Installation	55
AGP VxD Support Utility	56
System Requirements	56
Installation	56
BIOS Flash Software.....	57
Downloading BIOS File	57
Upgrading BIOS File.....	57
Loading New BIOS Defaults	57
Anti-Virus Tool.....	58
Hardware Requirements.....	58
Technical Notes	58