# Using HydraVision<sup>™</sup> for Windows<sup>®</sup> NT4.0/Windows<sup>®</sup> 2000

HydraVision<sup>™</sup> software is specifically designed for use with Windows<sup>®</sup>NT4.0 and Windows<sup>®</sup>2000. HydraVision<sup>™</sup> installation enables the Desktop Manager and creates a Windows<sup>®</sup> program group for HydraVision<sup>™</sup> display management software. The HydraVision<sup>™</sup> software is automatically installed with the ATI video drivers

HydraVision<sup>TM</sup> and the Desktop Manager are activated whenever Windows<sup>®</sup> starts. You can tell that HydraVision<sup>TM</sup> is running by the presence of the HydraVision<sup>TM</sup> icon in the Windows<sup>®</sup> system tray.



HydraVision<sup>TM</sup> System Tray Icon

Click on this icon to access HydraVision<sup>TM</sup> features and help, or to unload the HydraVision<sup>TM</sup> Desktop Manager.



Accessing HydraVision<sup>TM</sup>

The HydraVision<sup>™</sup> Desktop Manager allows you to modify your display options. You can access the **Desktop Management** and **Hot Keys** dialog boxes by clicking on the appropriate tab in the Desktop Manager.

Along the bottom of each HydraVision<sup>™</sup> dialog are four buttons: **OK**, **Cancel**, **Apply** and **Help**.

**OK** implements the changes you've made in the HydraVision<sup>™</sup> dialog and exits the Desktop Manager. Changes take effect immediately unless you see a message prompting you to restart your computer.

**Cancel** discards *all* changes made to any section of the HydraVision<sup>TM</sup> dialog and closes the Desktop Manager.

**Apply** implements your changes without closing the Desktop Manager.

**Help** connects to local or on-line HTML-based help. You can also get context -sensitive on-screen help by moving your mouse over the relevant text for each controller

## **Desktop Management Controls**



The Desktop Management Dialog Windows N4.0



The Desktop Management Dialog Windows 2000

The **Desktop Management** dialog lets you determine the behavior of pop-up windows and dialog boxes in a multiple monitor environment.

#### **Dialog control:**

**Enable dialog repositioning**—Toggles dialog control on and off. When it is checked, you can choose to have dialog boxes appear on the parent application's monitor (The parent application is the application that generated the dialog box.). If the parent application or associated monitor cannot be located, the dialog box defaults to monitor 1. You can also choose to have dialog boxes appear on the monitor in which the cursor is located or to always appear on a specific monitor in the array.

Window control:

**Single monitor windows**—When this box is checked, windows are sized no larger than a single monitor. Windows that are placed on monitor splits are automatically relocated to the monitor on which most of the window appears.

**HydraVision<sup>™</sup> Max button management**—Allows you to control the behavior of the Windows<sup>®</sup> **Maximize** button. When HydraVision<sup>™</sup> is running, a HydraVision<sup>™</sup> Max/Restore button appears in the upper right corner of your application title bars. Clicking this icon makes the active window maximize in one of two ways:

- **Max to window corners** causes windows to maximize to the monitor(s) that contain the window's upper left and lower right corners.

- **Max to full desktop** causes windows to maximize to the entire monitor array.

**Max child windows**—Keeps windows generated by parent applications from splitting across monitors (A child window is a window residing within a parent application window.) The ability to keep child windows on a single monitor when maximized is extremely useful for editing multiple documents side by side in a parent application. *A*→ *NOTE:* The HydraVision<sup>TM</sup> application title bar icon changes from a single square to two smaller squares when a window is in a HydraVision<sup>TM</sup> maximized state. Clicking the icon again restores the active window to its default state as a single square.

General:

**Application position memory**—Check this box to "remember" the size and location of application windows when they are closed and reapply those settings when the application is reopened.

**Boot to single monitor**—Check this box to enable a single monitor only when the computer starts. All other connected devises will be disabled. *Note:* Extended Desktop must be enabled before the computer is restarted.

**Enable individual application settings**—Check this box to specify desktop management settings for individual applications. You can access these settings by clicking on the down arrow of the HydraVision<sup>™</sup> icon in the application title bar or by clicking the **Individual Application Settings** button in the **Desktop Management** dialog.

**Remove ATI title bar buttons**—This box removes or restores the ATI buttons placed on the title bar in installed applications.

**Remove MultiDesk system tray icon**—This box removes or restores the MultiDesk system tray icon.

**MultiDesk Settings**—This button gives access to all the MultiDesk Properties. Here you enable, disable and name active desktops.

Load/Unload Desktop Manager—This button restores or removes the HydraVision<sup>TM</sup> Desktop Manager tracking program. You should only select this option if you do not want to use any multiple monitor dialog box and window controls or hot keys.

**Load/Unload MultiDesk**—This button restores or removes multiple desktop functionality.

**Individual Application Settings**—This button allows you to specify, enable and disable desktop management settings for individual applications.

AS NOTE: These settings override the global settings defined in the **Desktop Management** dialog.

# **Hot Keys Controls**

HydraVision	<u> </u>	
C Desktop Management G Hot Keys		
Modifier key Hot key No Modifier Shat F2 AA F3 Chi F4 Shit-AA P5 Shit-AA Chi F5 Shit-AA Chi F7 Shit-AA Chi F8 •	Hot key fungtion   Stassårge to Monitor   HydraVision Popup Menu   Run Application   Gather al Windows to Monitor 1   Find Custor   Switch to desktop scheme (K)   Next Desktop   Previous Desktop	
Agsigned hot keys Agd Rgmove		
Djsable hot keys		
OK	Cancel Apply Help	

The Hot Keys Dialog

HydraVision<sup>™</sup> allows you to specify hot key shortcuts for common operations such as starting applications, snapping applications to designated monitors, and changing display resolution.

#### **Create/Remove Hot Keys**

To create custom hot key sequences, select a **Modifier key** (Shift, Alt, etc.), a **Hot key**, and the **Hot key function** you want this key combination to perform. Click **Add** to enter your new combination in the **Assigned hot keys** list box. Click **Apply** to activate assigned hot keys.

 $\Leftrightarrow$  NOTE: ATI recommends that a modifier key be used with any function key (F1, F2, etc.) assigned as a hot key. This will prevent interference with the function of these keys in individual applications.

To delete a hot key from the **Assigned hot keys** list box, highlight it, click **Remove**, and then click **Apply.** 

You can also disable all hot keys listed in the **Assigned hot keys** list box by checking the **Disable hot keys** box near the bottom of the **Hot Keys** dialog.

### **Using Hot Keys**

You can use any assigned hot key at any time, from within any application, to change your display.

Provided hot key functions include:

Snap App to Monitor	Allows you to move or "snap" active
	windows or dialogs from monitor to
	monitor for quick placement and
	viewing of desktop contents.
HydraVision <sup>™</sup> Pop-up	Allows on-the-fly access to
Menu	HydraVision <sup>™</sup> controls.
Run Application	Lets you start any application with a hot
	key.
Gather All Windows to	Allows you to find applications that are
Monitor 1	hidden or are open and lost on disabled
	monitors.
Find Cursor	Locates the cursor on a busy or crowded
	desktop
Next Desktop	Accesses other active desktops
Zoom Display In/Out	Causes the desktop resolution to increase
	or decrease.
Zoom In/Out on	Causes the resolution of the active
Monitor	monitor to increase or decrease.

# **MultiDesk**

HydraVision<sup>™</sup> software supports multiple desktops. With MultiDesk, one active desktop will always be visible, while up to eight active desktops can reside in the background. When MultiDesk is running, the MultiDesk icon in the system tray displays the number assigned to the current desktop



MultiDesk System Tray Icon

Right-click on this icon to access MultiDesk controls. In addition to accessing active desktops from the system tray, you can also access active desktops with a **Hot key** shortcut



#### MultiDesk Pop-Up Menu

To switch to another defined desktop, select the appropriate desktop number from the pop-up menu. To enable, disable and name active desktops, select **MultiDesk Properties** from the pop-up menu. The MultiDesk functionality can be removed by selecting **Unload HydraVision**<sup>TM</sup> **MultiDesk** from the pop-up menu. **MultiDesktop Properties** allows you to control the desktops. Rightclick a Desktop tab to set it Active, Inactive, or Disabled. Inactive Desktops MAY contain applications however they are temporarily disabled. Disabled Desktops cannot contain any applications. If an Active or Inactive desktop is disabled which contain applications they will be automatically moved to an Active desktop.

You can also give a desktop a unique name. Double-click the desired desktop tab. The tab will turn grey and the cursor will blink. Simply type in the new name. When you have finished renaming the desktop click on the tab to save the change.

**Keep on all desks** allow you to have a selected application visible on all desktops.